



Remove 4 screws holding fan impeller, take fan impeller out. Make sure to mind the cable.